When changing a refill in your Cross ballpoint pen, please, follow the instructions below:

Most Cross ballpoint pens are supplied with <u>SCREW-IN mechanisms</u>. When you want to <u>remove</u> an old refill, you have to <u>unscrew</u> the refill from the barrel. Once you want to <u>insert</u> a new one, you have to <u>screw</u> a refill <u>in</u>.

When replacing your refill:

- 1. Remove the pen cap.
- 2. Turn the colored refill tip (located inside the internal mechanism chrome) counter clockwise and remove.
- 3. Before inserting your new refill, it is <u>very important</u> that you <u>turn the internal mechanism</u> (<u>chrome</u>) <u>counter clockwise</u> until you can no longer twist it.
- 4. Insert the new refill by twisting (turn clockwise).
- 5. Place the cap.

When inserting your new refill, please, **note step number three**. If the internal mechanism is not turned completely counter clockwise, the refill will not engage properly.

A.T. CROSS wishes you many years of fine writing pleasure. Glad to be at your service.