


OPERATING INSTRUCTIONS - 0.9MM PENCILS



TO OPERATE PENCIL: turn the pencil cap clockwise until a short length of lead is exposed.

TO REPLACE LEAD:

- the pencil must be cleared of old lead before inserting the new lead.
- turn cap clockwise until **all** unused lead is expelled from pencil.
- gently turn the cap counter clockwise until it stops.
- remove the cap by pulling it from the barrel.
- leads are stored under the eraser holder. Pull eraser from barrel. Select a lead.
- place back the eraser and cap.
- insert the lead into the pencil point until it stops.
- turn clockwise until the lead extends 1/8".
- press the lead **gently** against a firm surface so the lead is gripped by the pencil mechanism.